


Mastercam X⁵


Shared customizable files



Files that can be accessed and changed by all users

Art	Design Library, materials, etc.
ATP	Definitions, levels, strategies
CNC_MACHINES	Machine/Control Definitions
common	Support data (editor, FBM, reports), parameters
common\editors	Mastercam editor files: languages, Machines, member-lists, Multitask
common\FBM	FBM config and setup (map)
common\PRM	General parameters
common\reports	Nesting tool/material lists, ATP, post labels, Active Reports setup sheets
data	Translator data
DESIGN	Solid layout template
engrave	Support and data files; rast-2surf; rast2vec
lathe	Lathe default operations, posts, SET files, and tools
MATERIALS	Default materials
mcx	Sample files, templates
MILL	Mill default operations, POSTS, SET files, and tools
MILL\FORMULA	HST formula files
ModuleWorks\MachSim	Machine Simulation machine models
NESTING	Nesting files
ROUTER	Router default operations, SET files, posts, templates, and tools
vb	VBScripts
WIRE	Wire default operations, posts, and power libraries


Single-user customizable files



Files that can be accessed and changed by a single user

BATCH	Batch files for batch post processing
CONFIG	Configuration (CONFIG), key maps (KMP), toolbar states (MTB), and MD/CD defaults
data	Single user data files
Event logs	Events, error log
Lathe	Lathe NC and NCI
MCX	Mastercam part files
Mill	Mill NC and NCI
REGEN	Regen files
Router	Router NC and NCI
Wire	Wire NC and NCI

Non-customizable



Files that can be accessed by all users but cannot be changed

Art Machine	Art toolpath support data
documentation	Mastercam documentation
Chooks	3rd party applications
common	Defaults, editors, fonts
resources	resources for language translation

If you are looking for these files...	...look here.
Application files (DLL)	..\Program Files\mcamx5\
Art presets, cross sections, Design Library, materials, etc.	..\shared mcamx5\Art
Art Machine	..\Program Files\mcamx5\Art\Art Machine
ATP material and sheet definitions (XML), level scans, etc.	..\shared mcamx5\ATP
Batch post processing	..\User\My Documents\my mcamx5\BATCH
Chooks	..\Program Files\mcamx5\chooks
Config files, Key maps (KMP), Toolbar states (MTB)	..\User\My Documents\my mcamx5\CONFIG
Data	..\User\My Documents\my mcamx5\data
Documentation	..\Program Files\mcamx5\Documentation
Editor config and setup files	..\shared mcamx5\Common\editors
FBM	..\shared mcamx5\Common\FBM
Engraving toolpath and data files, rast2surf, rast2vec	..\shared mcamx5\engrave
HST formula files (XML)	..\shared mcamx5\MILL\FORMULA
Fonts	..\Program Files\mcamx5\Common\Fonts
Lathe defaults	..\shared mcamx5\LATHE\Ops
Machine and Control Definitions	..\shared mcamx5\CNC_MACHINES
Mastercam Simulation files	..\shared mcamx5\Module Works\MachSim
Material lists	..\shared mcamx5\Common\reports
Materials defaults	..\shared mcamx5\MATERIALS
Mill defaults	..\shared mcamx5\MILL\Ops
NC and NCI	..\User\My Documents\my mcamx5\[product]\[NC, NCI]
Nesting files (NSLX, DEFX, NSTX)	..\shared mcamx5\NESTING
Parameters	..\shared mcamx5\Common\PRM
Posts	..\shared mcamx5\[product]\Posts
Regen files	..\User\My Documents\my mcamx5\REGEN
Reports	..\shared mcamx5\Common\reports
Router defaults	..\shared mcamx5\ROUTER\Ops
Sample MCX files	..\shared mcamx5\mcx\[product]
Solid layout templates	..\shared mcamx5\DESIGN
Setup sheets (SET files)	..\shared mcamx5\[product]\Posts
Setup sheets (Active Reports)	..\shared mcamx5\Common\reports
Templates (MCX)	..\shared mcamx5\mcx\Templates
Tool lists	..\shared mcamx5\Common\reports
Tools	..\shared mcamx5\[product]\Tools
Translator sample files	..\shared mcamx5\data\Translators
VBScripts	..\shared mcamx5\VB
Wire defaults	..\shared mcamx5\WIRE\Ops