



Getting Started Series Tutorials

Basic 2D Design

Basic 2D Design

August 2009

Be sure you have the latest information!

Information might have been changed or added since this document was published. The latest version of this document is installed with Mastercam or can be obtained from your local Reseller. The ReadMe file (ReadMe.htm) includes the latest information about new features and enhancements.

Mastercam® X4 Basic 2D Design

Date: August 2009

Copyright © 2009 CNC Software, Inc.— All rights reserved.

First Printing: August 2009

Software: Mastercam X4

Part Number: X4-PDF-TUT-2D

TERMS OF USE

Use of this document is subject to the Mastercam End User License Agreement. A copy of the Mastercam End User License Agreement is included with the Mastercam product package of which this document is part. The Mastercam End User License Agreement can also be found at:

www.mastercam.com/legal/licenseagreement/

Contents

.....


Introduction	1
▶ Tutorial Goals.....	1
▶ Before You Begin.....	1
▶ If You Need More Help.....	2
▶ Additional Documentation.....	3
 1. Creating Lines and Arcs	 5
▶ Lesson Goals.....	5
▶ Exercise 1: Drawing Vertical Lines.....	5
▶ Exercise 2: Drawing Horizontal Lines	7
▶ Exercise 3: Drawing Angled Lines and Circles	9
▶ Exercise 4: Trimming the Outer Contour	10
 2. Creating Drill Holes	 13
▶ Lesson Goals.....	13
▶ Exercise 1: Drawing the First Drill Hole.....	13
▶ Exercise 2: Creating Additional Holes	14
 3. Modifying Geometry.....	 17
▶ Lesson Goals.....	17
▶ Exercise 1: Offsetting the Outer Contour.....	17
▶ Exercise 2: Adding Tangent Lines.....	18
▶ Exercise 3: Trimming the Inner Contour	20
▶ Exercise 4: Mirroring the Drill Holes.....	21
▶ Exercise 5: Trimming the Mirrored Geometry	23
▶ Exercise 6: Adding Fillets	24
 4. Adding a Slot.....	 27
▶ Lesson Goals.....	27
▶ Exercise 1: Starting the Slot	27
▶ Exercise 2: Drawing Lines for the Slot	28

- ▶ Exercise 3: Completing the Slot Geometry29
- ▶ Exercise 4: Changing the Slot’s Color and Level.....29

Conclusion31

INTRODUCTION

Mastercam provides many functions for creating and editing your part geometry, from simple 2D wireframe to complex 3D surface models. The *Basic 2D Design* module focuses on teaching you the 2D wireframe CAD tools used to draw the following part.



Tutorial Goals

- Draw basic geometry such as lines, arcs, and fillets.
- Set and change entity attributes.
- Select and chain geometry.
- Use AutoCursor and Visual Cues.
- Transform geometry.
- Trim geometry.

Before You Begin

This is a module of the *Mastercam Getting Started Tutorial Series*, which introduce basic Mastercam skills. Other tutorial series, which cover more advanced skills, are:

- *Focus Series*—This series provides more in-depth training on specific or advanced Mastercam features and functions.
- *Exploring Series*—This series explores the application of a single Mastercam product, such as Mill, Wire, or Art.

The Mastercam tutorial series is in continual development, and we will add modules as we complete them. For information and availability, please contact your local Mastercam Reseller.

Note: Screen colors in the tutorial pictures enhance image quality; they may not match your Mastercam settings.

General Tutorial Requirements


Because each lesson in the tutorial builds on the mastery of preceding lesson's skills, we recommend that you complete them in order. In addition, the tutorials in this series have the following requirements:

- You must be comfortable using the Windows® operating system.
- You must have a seat of Mastercam X4 Design or higher to complete most of the tutorials in the *Getting Started* series. The tutorials cannot be used with Mastercam Demo/Home Learning Edition.
- The *Basic 2D Machining* tutorial requires a seat of Mill Entry or Router Entry. Tutorials in other series may require higher level licenses.
- Part files may accompany a tutorial. They should be stored in a folder with the tutorial or in a location that you prefer.
- You must configure Mastercam to work in metric units. The next section includes instructions for setting Mastercam to metric.

Preparing for a Tutorial


Before you start a tutorial, be sure you have completed the following tasks:

- 1 Start Mastercam using your preferred method:
 - ♦ Double-click Mastercam's desktop icon.
 - Or
 - ♦ Launch Mastercam from the Windows Start menu.
- 2 Select the metric configuration file:
 - a Select **Settings, Configuration** from Mastercam's menu.
 - b Choose **..\config\mcamxm.config** <Metric> from the **Current** drop-down list.
 - c Click **OK**.



If You Need More Help

There are many ways to get help with Mastercam, including the following:

- *Mastercam Help*—Access Mastercam Help by selecting **Help, Contents** from Mastercam's menu bar or by pressing [**Alt+H**] on your keyboard. Also, most dialog boxes and ribbon bars feature a Help button  that opens Mastercam Help directly to related information.
- *Online help*—You can search for information or ask questions on the Mastercam Web forum, located at www.emastercam.com. You can also find a wealth of information, including many videos, at www.mastercam.com and www.mastercamedu.com.
- *Mastercam Reseller*—Your local Mastercam Reseller can help with most questions about Mastercam.
- *Technical Support*—CNC Software's Technical Support department (860-875-5006 or support@mastercam.com) is open Monday through Friday from 8:00 a.m. to 5:30 p.m. USA Eastern Standard Time.
- *Documentation feedback*—For questions about this or other Mastercam documentation, contact the Technical Documentation department by email at techdocs@mastercam.com.
- *Mastercam University*—CNC Software sponsors Mastercam University, an affordable, online learning tool with more than 180 videos to let you master your skills at your own pace. For more information on Mastercam University, please contact your Authorized Mastercam Reseller, visit www.mastercamu.com, or email training@mastercam.com.

Additional Documentation

You can find more information on using Mastercam in the following materials, located in the \Documentation folder of your Mastercam installation:

- *Mastercam X4 Installation Guide*
- *Mastercam X4 Administrator Guide*
- *Mastercam X4 Quick Start*
- *Mastercam X4 Reference Guide*
- *Mastercam X4 Transition Guide*
- *Mastercam X4 Quick Reference Card*
- *Mastercam X4 Wire Getting Started Guide*
- *Version 9 to X Function Map*

LESSON 1

Creating Lines and Arcs

Lines and arcs are some of the most standard geometry used in 2D parts. This lesson introduces you to some of Mastercam's line and arc creation methods as you begin drawing the outer shape of the tutorial part.

Lesson Goals


- Draw lines and arcs.
- Work with live entities.
- Trim geometry.

Exercise 1: Drawing Vertical Lines

In this exercise, you start creating your part by drawing vertical construction lines.



- 1 Press **[F9]** to display the XY axes in the graphics window.

The coordinate axes show the origin and the part orientation to help you visualize the part in 3D space.



- 2 Choose **Create, Line, Endpoint** from the Mastercam menu.

Mastercam displays the Line ribbon bar and prompts you to select the first endpoint.



Ribbon bars display based on what function you are using. Each ribbon bar includes options for the specific task you are doing. The Line ribbon bar has options for creating a line by selecting two endpoints.




TIP: You can click and drag the yellow prompt window to any position.

Specify the first endpoint


- 3 Select the origin as your first endpoint by moving your cursor to the center of the graphics window where the X and Y axes cross. The cursor changes to an arrow with a star icon next to it.

This is the **AutoCursor**, which lets you quickly select and enter points. The **Visual Cues** icon attached to the AutoCursor changes depending what type of geometry you are near. This icon indicates that you are at the origin.



- 4 Click the origin and move your cursor vertically along the Y axis.

The Visual Cue changes to the Horizontal/Vertical icon. This confirms that you are drawing a vertical line.





- 5 Click anywhere along the Y axis to set a temporary line length. The line changes to blue and is now considered a live entity.

Live entities can be modified by changing values in the ribbon bar until you exit the function, start a new function, begin to create another entity, or click **Apply**. Once you begin another entity or exit the function, the entity becomes *fixed* and is no longer editable through the ribbon bar.



- 6 On the Line ribbon bar, enter **50** for the line length. This creates a 50 mm vertical line.
- 7 Click the **Apply** button on the ribbon bar.
The line is now fixed, but you stay in the Line function so you can draw more lines.
- 8 Right-click anywhere in the graphics window, and choose **Fit** from the pop-up menu. This changes the graphics view so all geometry fits in the graphics window.




TIP: The right-click menu has many functions that are used often. You can customize this menu to display the functions you use most by choosing **Settings, Customize** and changing the settings on the **Drop downs/Right mouse button menu** tab. For more information on how to do this, click the **Help** button on the Customize dialog box.

Exercise 2: Drawing Horizontal Lines


In this exercise, you draw additional horizontal construction lines.

- 1 Click the **Length** button on the Line ribbon bar.



This locks the value, which is useful when you want to create multiple lines with the same length. The field also turns red to indicate that it is locked.

- 2 Click the **Horizontal** button. The button remains pressed in. This means that the next line you draw will be horizontal.





- 3 Move your cursor to the top endpoint of the first line. The AutoCursor highlights the line and the Visual Cue changes to indicate an endpoint.
- 4 Click the endpoint. Because your direction and length are fixed, you only have two options - to the left or right of the endpoint. Move your cursor left and right to see the two possible lines.




- 5 Click to the right of the first line to set the new line position. Notice that the new line is a live entity.
- 6 Press **[Enter]** twice to complete the line.
- 7 Click **Length** on the ribbon bar again to unlock the field. The next line you draw will be a different length.
- 8 Select the origin again as the first endpoint and drag your cursor to the right along the X axis. You are creating another horizontal line because the **Horizontal** button is still selected.



Note: Make sure that the Visual Cue indicates the origin,  not the line endpoint. 


- 9 Click anywhere to set a temporary length, and type **95** for the length in the ribbon bar.
- 10 Press **[Enter]** twice to complete the line.
- 11 Right-click again in the graphics window and choose **Fit** to see all the lines.



Exercise 3: Drawing Angled Lines and Circles

In this exercise, you draw an angled line, and use the Create Line Parallel function to draw a parallel angled line. You also use the Create Circle Edge Point function to draw a circle using two points.


- 1 Deselect **Horizontal**. The next line is at an angle.
- 2 Press [**Page Down**] several times to zoom out from the part. This gives you room to draw the angled line.
- 3 Click the right endpoint of the 95 mm line, and drag your cursor up to the right at an angle.
- 4 Click anywhere to create the live entity.



- 5 Enter **50** for the line length and **30** for the angle.
- 6 Click **Apply** to complete the line.
- 7 Click **OK** to close the Line ribbon bar.




- 8 To draw a line that is parallel to the angled line, choose **Create, Line, Parallel** from the menu bar. This opens the Line Parallel ribbon bar.



TIP: You can also access the menu bar using the keyboard. Press [**Alt**] to display the shortcut keys for each menu option. For example, you could press **Alt, C, L, A** to access the Create Line Parallel option.


- 9 Select the angled line, and then click anywhere above the line. Mastercam creates a live parallel line entity.
- 10 Enter **50** for the distance and click **OK**.
- 11 To add an arc to the end of the part, choose **Create, Arc, Circle Edge Point**.




- 12** Select the **Two Point** button on the Circle Edge Point ribbon bar.



- 13** Select the upper endpoints of the two angled lines.



- 14** Click **OK** to complete the arc.



Exercise 4: Trimming the Outer Contour

In this exercise, you trim the construction geometry together to complete the part's outer contour.

- 1** Choose **Edit, Trim/Break, Trim/Break/Extend**.


- 2** Select the **Trim 2 Entity** button on the ribbon bar.



This function trims two entities to their nearest intersection.

- 3** Select the top angled line and the top horizontal line.

You should select the piece of the entity that you want to keep. In this example, you want to keep the left side of the horizontal line and the top of the angled line. The gray dotted line indicates the section that will be trimmed.



TIP: *If the result does not look correct, choose **Edit, Undo** to remove the trimming, and try selecting the geometry again.*




- 4 To trim the circle to the two angled lines, click the **Divide/Delete** button on the ribbon bar.




This function divides entities based on the nearest intersection.


- 5 Select the left-hand side of the circle.



- 6 Click **OK** to complete the trimming. Your part should look like the picture at right.



- 7 Choose **File, Save** to save the geometry you have created. The Save As dialog box displays because you are saving the file for the first time.



- 8 Type `OUTER_CONTOUR.MCX` in the **File Name** field.
- 9 Click **OK** to save the file.

Note: For more information on saving files, refer to the Mastercam Help.

Now that you have created the basic outline of your part, you will add drill holes in the next lesson.

LESSON 2

Creating Drill Holes

Mastercam makes it easy to quickly add arcs to your part. This lesson focuses on additional methods for drawing circles that can later be used as drill holes.


Lesson Goals

- Set entity attributes.
- Use relative positioning.
- Work with AutoCursor.


Exercise 1: Drawing the First Drill Hole

In this exercise, you draw a circle using FastPoint mode on a different level.

- 1 Open `OUTER_CONTOUR.MCX`, which was provided with this tutorial, or continue using the MCX file you created in Lesson 1.



- 2 Click in the **Level** field on the Status bar at the bottom of the screen, and type **2** to start a new level. All new entities will be placed on Level 2.



Levels are an organizational tool in Mastercam that help you control what areas of your part are visible or selectable. For more information on levels, refer to the online Help.

- 3 To draw the first set of holes, choose **Create, Arc, Circle Center Point** from the Mastercam menu.
- 4 Press [**Spacebar**] to enter FastPoint mode, which can be accessed whenever a coordinate value is required. A field pops up on the AutoCursor ribbon bar.




The FastPoint field lets you type in point coordinates with or without the corresponding coordinate letters (X, Y, Z).

TIP: You can also enter fractions and formulas in the FastPoint field.




- 5 Type **10, 10** for the first circle center point and press **[Enter]**.



- 6 Move your cursor to the graphics window. A temporary circle displays centered on the point you entered.

- 7 Click to set a temporary diameter and create the live entity.




- 8 Enter **10** in the Diameter field on the Circle Center Point ribbon bar, and then click the **Diameter** button to lock the value.



Locking the field lets you draw a second circle with this same diameter.

*Note: The **Radius** field is also locked. When you enter either a radius or a diameter, the other field also updates.*

- 9 Click **Apply** to complete the circle.



Exercise 2: Creating Additional Holes

In this exercise, you draw three additional drill holes using relative positioning and the AutoCursor.

- 1 Hold down the **[Shift]** key, and click the center point of the first circle. The Relative Position ribbon bar displays.

You can now create the second center point relative to the existing point.



TIP: You can position new points relative to any existing geometry by holding the **[Shift]** key and clicking an existing point.





- 2 Type **x50** in the Delta field and press **[Enter]**.

The live entity is created, and you return to the Circle Center Point ribbon bar.


- 3 Click **Apply** to create the second hole.
- 4 Click the **Diameter** button to unlock the value.



- 5 Enter **7.5** for the **Radius**, and re-lock the fields. The next two circles will be the same size.
- 6 To draw the third hole, select the center of the first hole. When you get close, AutoCursor snaps to the center point and displays a Visual Cue. Click the center point, and click **Apply** to make the third circle.



- 7 Click the center point of the right circle to make the last circle.
- 8 Click **OK** to exit the function.
- 9 Choose **File, Save As**.
- 10 Save the file as
OUTER_CONTOUR_WITH_HOLES.MCX.



Two of the circles you completed will be used as drill holes and the other two will be used in the next lesson to create the inner shape of the part.

LESSON 3

Modifying Geometry

Once you have your construction geometry, Mastercam provides many tools for editing and trimming the individual pieces into your final part shape. In this lesson, you use some of these tools, along with some of Mastercam's geometry selection methods.


Lesson Goals

- Offset and mirror geometry.
- Use General Selection.
- Use the data entry calculator and the MRU toolbar.
- Delete duplicate geometry.
- Create fillets.

Exercise 1: Offsetting the Outer Contour


In this exercise, you use the Xform Offset Contour function to begin creating the inner contour of the part.

- 1 Open the tutorial part:
OUTER_CONTOUR_WITH_HOLES.MCX or
continue using the MCX file you created in
Lesson 2.
- 2 Choose **Xform, Offset Contour** from the
Mastercam menu. The Chaining dialog box
displays.




This function uses *chaining*, which lets you select one or more entities linked together by adjoining endpoints. Chaining is different from other selection methods because it associates order and direction with the selected entities. For more information, click the **Help** button on the Chaining dialog box.

- 3 Click anywhere along the outer contour.
Mastercam selects and highlights all of the
geometry.
- 4 Click **OK** on the Chaining dialog box.



- 5 On the Offset Contour dialog box, make sure that the **Copy** option is selected, enter **2.0** for the distance, and press [Tab] to check the position of the offset contour.




*Note: If the offset contour (purple) is displaying on the outside of the selected chain, click the **Direction** button to flip it to the inside.*



- 6 Click **OK**. The original contour is red and the new contour is purple.

Mastercam creates a temporary group from the original geometry (red) and another temporary group from the result (purple). **Groups** gather entities into a single unit for selection. For more information on groups, refer to the online Help.



Exercise 2: Adding Tangent Lines

In this exercise, you draw perpendicular lines that are tangent to the drill holes.


- 1 Choose **Create, Line, Perpendicular** from the Mastercam menu.
- 2 Select the **Tangent** button on the Line Perpendicular ribbon bar.




This setting ensures that the new line will be tangent to an arc you select.

- 3 Click the left outer circle and the left inner line.


Mastercam displays two lines as possible solutions.




- 4** Click the top line to keep this solution.




- 5** Click the left outer circle again and the lower inner line. Mastercam again displays two solutions.



- 6** Click the right line.



- 7** Click the right outer circle and the lower inner line.
To create tangent lines on either side of the right drill hole, you need to select the same geometry twice.




- 8** Click the right line to keep.




- 9 Click the right outer circle and the lower line again.
- 10 Click the left line to keep.



TIP: If you do not see all four lines, right-click in the graphics window and choose **Repaint**. This refreshes the graphics window.



- 11 Click **OK** to complete the lines.



Exercise 3: Trimming the Inner Contour

In this exercise, you trim the geometry around the drill holes.


- 1 Choose **Edit, Trim/Break, Trim/Break/Extend**.
- 2 Click the **Trim 1 entity** button on the ribbon bar.




This function allows you to select the entity you want to trim, and then select the location you want to trim to.

- 3 Click the left outer circle as shown at right.
- 4 Click the top tangent line.

*Note: It is important to select the geometry in this specific order, or the trimming results will be different. If the results do not match the pictures at right, choose **Edit, Undo**, and try reselecting the geometry.*



- 5 Click the right outer circle as shown at right.
- 6 Click the left tangent line.





- 7 Click the **Divide/Delete** button on the ribbon bar.



Note: You can also press the shortcut key [D].

- 8 Click the following three points:
 - ♦ the inner contour line to the left of the left drill hole.
 - ♦ the inner contour line below the left drill hole.
 - ♦ the inner contour line below the right drill hole.
- 9 Click **OK** to complete the trimming.



Exercise 4: Mirroring the Drill Holes


In this exercise, you use General Selection to select a section of the part and mirror the selected area to a position along the top edge of the part.

- 1 Choose **Xform, Mirror** from the Mastercam menu.
- 2 On the General Selection ribbon bar, make sure that the Entity selection drop-down is set to **In**.


This selects only entities that lie completely in your selection window.




- 3 Press [Page Down] a few time to provide space in the graphics window for selection.
- 4 To select the area of the part that you just created, click and hold the mouse button above and to the left of the left drill hole.
- 5 Drag your mouse down and to the right to draw a selection rectangle.



- 6 Click again to set the lower right corner of the rectangle and complete the selection.




- 7 Click the **End Selection** button on the General Selection ribbon bar to complete the geometry selection and open the Mirror dialog box.
- 8 On the Mirror dialog box, select the first **Axis** option, which mirrors the geometry about the X axis. Make sure that the **Copy** option at the top of the dialog box is selected.
- 9 Enter **50/2** for the Y value and press [Tab]. Mastercam displays a temporary center line at Y25 to show the horizontal axis that will be used to mirror the selected entities.



Since the left line is 50mm, this Y value mirrors the geometry to the other side of the part.

*Note: All fields that take number values have a built-in calculator that accepts formulas, math equations, and other units of measurement. For more on this function, type **calculator** on the Index tab in Mastercam Help.*

- 10 Click **OK** to mirror the geometry.



Exercise 5: Trimming the Mirrored Geometry

In this exercise, you trim the contour around the mirrored drill holes and delete the resulting duplicate geometry.

- 1 Click the **Trim/Break/Extend** button on the Most Recently Used (MRU) toolbar.


This toolbar shows the last several functions that you used in Mastercam.

- 2 Make sure the **Divide** button is still selected on the ribbon bar.


Mastercam keeps the settings from the last time you used the function.



- 3 Click the following three points:
- ♦ the inner contour line to the left of the top left drill hole.
 - ♦ the inner contour line above the top left drill hole.
 - ♦ the inner contour line above the top right drill hole.




4 Click **OK** to complete the trimming




5 To remove duplicate geometry, choose **Edit, Delete, Delete Duplicates** from the Mastercam menu.

In trimming the lines, a duplicate line was created. The resulting message describes what duplicate geometry was found and removed.


Duplicate entities can make files larger than necessary and make chaining more difficult.



TIP: You can also click the toolbar button to use this function. Click the drop-down arrow next to the button and select **Delete Duplicates**.



6 Click **OK** to accept the change.




Exercise 6: Adding Fillets

In this exercise, you complete the inner contour by adding fillets to the sharp corners.


1 Choose **Create, Fillet, Chains** from the Mastercam menu.



- 2 Click anywhere along the inner contour. Mastercam highlights the whole contour.
- 3 Click **OK** on the Chaining dialog box. Since you already have some fillets along this contour, Mastercam asks if you want to change the radius on all the existing fillets.




- 4 Click **No** to just add new fillets.
- 5 Click **OK** on the Fillet Chains ribbon bar to accept the new fillets.



- 6 Right-click in the graphics window, and choose **Clear Colors** to return all geometry to its original color.

*Note: You can also choose **Screen, Clear Colors** from the menu bar.*



- 7 Choose **File, Save As**.
- 8 Save the file as OUTER_INNER_CONTOURS.MCX.

The outer contour, inner contour, and drill holes are now complete. The last lesson adds a slot to the rounded end of the part.

LESSON 4

Adding a Slot

The final section of the tutorial part is a slot on the rounded end. In this lesson, you will draw the slot and change the color and level of the resulting geometry.



Lesson Goals

- Offset arcs.
- Change entity attributes.


Exercise 1: Starting the Slot

In this exercise, you offset an existing arc to begin the slot.


- 1 Open the tutorial part:
OUTER_INNER_CONTOURS.MCX or continue
using the MCX file you created in Lesson 3.
- 2 From the Mastercam menu, choose **Xform**,
Offset.
- 3 On the Offset dialog box, enter **8** for the
distance. Make sure that the **Copy** option
at the top of the dialog box is selected.



- 4 Select the arc on the rounded end of the inner contour.
- 5 Click inside the arc to indicate the offset direction.



- 6 Click **OK** to create the new arc.



Exercise 2: Drawing Lines for the Slot

In this exercise, you draw lines for the sides of the slot using the first arc's endpoints.


- 1 Choose **Create, Line, Endpoint**.
- 2 Enter **25** for the length and **210** for the angle in the ribbon bar. Lock both fields because you will draw two lines with the same attributes.




*Note: Make sure the **Tangent** button is deselected.*



- 3 Click the two endpoints of the offset arc that you made in the previous exercise. The AutoCursor snaps to the two endpoints.




- 4 Click **OK** on the ribbon bar to complete the lines.




Exercise 3: Completing the Slot Geometry

In this exercise, you use the endpoints of the two lines to make the slot's second arc.

- 1 Choose **Create, Arc, Arc Endpoints**.
- 2 In the ribbon bar, enter **15** for the radius.
- 3 Click the line endpoints at the open end of the slot. Mastercam gives you two possible arcs using the selected endpoints and radius.
- 4 Click the arc on the left.
- 5 Click **OK** on the ribbon bar to complete the arc.



- 6 Choose **Screen, Clear Colors** from the menu bar.





Exercise 4: Changing the Slot's Color and Level

In Lessons 2 and 3, you placed all new geometry on Level 2. In this exercise, you move the whole slot to a new level and change the geometry color.


- 1 On the General Selection ribbon bar, choose **Chain** from the Selection Methods drop-down list.

This option selects entities that are connected to other entities.




TIP: The Visual Cue with the red mouse button  indicates that if you right-click on an option in the drop-down list, you lock General Selection into that selection method. For more information, refer to the online Help.

- 2 Select anywhere on the slot. Mastercam highlights the whole slot.



- 3 Right-click the **Attributes** button in the Status bar.


The Attributes dialog box displays so you can change one or more entity attributes at the same time.




- 4 Select the check box next to the **Color** option, and enter **138** to change the slot to orange.
- 5 Select the check box next to the **Level** option, and enter **3** to move the slot geometry to Level 3.

Note: If Level 3 does not already exist, Mastercam creates a new level and moves the geometry there when you close the dialog box. For more information on levels, refer to the online Help.

- 6 Click **OK** to finish the changes.



- 7 Choose **File, Save As**.
- 8 Save the file as `PART_COMPLETE.MCX`.



Conclusion

Congratulations! You have completed the *Basic 2D Design* tutorial. Now that you have mastered the skills in this tutorial, we encourage you to explore Mastercam's other features and functions. Additional tutorials may be available in this or other series. Please contact your authorized Mastercam Reseller for further training.



cnc software, inc.

671 Old Post Road
Tolland, CT 06084 USA
www.mastercam.com

Printed in the USA

Mastercam X4 Getting Started Series - Basic 2D Design: Part X4-PDF-TUT-2D